



MAINTENANCE PARTS LIST FOR SFFGII BURNER

In order to keep the combustion equipment in the best condition,
we recommend the following parts for periodic replacement.

Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
1	ATOMIZER	Once a Year	
2	CAP NUT		
3	GLAND PACKING OF SPRAYER		
4	GASKET OF SPRAYER		
5	PACKING OF SPRAYER		
6	SPRING OF SPRAYER		
7	PLUG OF SPRAYER		
8	PACKING FOR SPRAYER CARRIAGE BALL VALVE		
9	GASKET FOR SPRAYER CARRIAGE BALL VALVE		
10	PACKING AND DUST COVER OF AIR CYLINDER		
11	IGNITION TIP		
12	GUIDE RING SEAL PACKING	Once every 3 years	
13	SWIRLER		
14	SIGHT GLASS		
15	MAIN GAS NOZZLE		
16	PILOT GASS NOZZLE		
17	GAS SPOKE	Once every 5 years	
18	SPRAYER		
19	SPRAYER CARRIAGE BALL VALVE FOR OIL SIDE		
20	SPRAYER CARRIAGE BALL VALVE FOR STEAM SIDE		
21	LIMIT SWITCH		
22	SPEED CONTROLLER		

*Earlier replacement may be needed depending on the operating condition.

*Parts other than those listed above also need to be replaced depending on the condition.

Please contact Japanese trading company to obtain a quotation for spare parts along with this check list.

In case you do not have business with Japanese trading company, please email us to

"info-m@volcano.co.jp".

We will send you contact details of the trading company by return.