



MAINTENANCE PARTS LIST FOR SFFG BURNER

In order to keep the combustion equipment in the best condition, we recommend the following parts for periodic replacement.

List of Periodic Replacement Parts

No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
1	ATOMIZER	Once a Year	
2	CAP NUT		
3	GLAND PACKING OF SPRAYER		
4	GASKET OF SPRAYER		
5	PACKING OF SPRAYER		
6	SPRING OF SPRAYER		
7	PLUG OF SPRAYER		
8	PACKING FOR SPRAYER CARRIAGE BALL VALVE		
9	GASKET FOR SPRAYER CARRIAGE BALL VALVE		
10	PACKING AND DUST COVER OF AIR CYLINDER		
11	IGNITION TIP		
12	GUIDE RING SEAL PACKING		
13	SWIRLER	Once every 3 years	
14	SIGHT GLASS		
15	PREMIXING GAS NOZZLE		
16	OUTER-MIXING GASS NOZZLE		
17	GAS SPOKE		
18	SPRAYER	Once every 5 years	
19	SPRAYER CARRIAGE BALL VALVE FOR OIL SIDE		
20	SPRAYER CARRIAGE BALL VALVE FOR STEAM SIDE		
21	LIMIT SWITCH		
22	SPEED CONTROLLER		

*Earlier replacement may be needed depending on the operating condition.

*Parts other than those listed above also need to be replaced depending on the condition.

Please contact Japanese trading company to obtain a quotation for spare parts along with this check list.

In case you do not have business with Japanese trading company, please email us to "info-m@volcano.co.jp".

We will send you contact details of the trading company by return.