



MAINTENANCE PARTS LIST FOR SFVFT BURNER

In order to keep the combustion equipment in the best condition,
we recommend the following parts for periodic replacement.

List of Periodic Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
1	F.O. ATOMIZER	Once a Year	
2	CAP NUT		
3	PILOT ATOMIZER		
4	IGNITION ELECTRODE		
5	SWIRLER		
6	SENSOR FOR FLAME EYE (PHOTO CELL)		
7	OIL SEAL FOR PUMP		
8	COUPLING RUBBER		
9	GLAND PACKING OF SPRAYER		
10	GASKET OF SPRAYER		
11	PACKING OF SPRAYER		
12	SPRING OF SPRAYER		
13	PLUG OF SPRAYER		
14	PACKING OF BALL VALVE		
15	GASKET OF BALL VALVE		
16	GUIDE RING SEAL PACKING		
17	SIGHT GLASS	Once every 3 years	
18	FLEXIBLE HOSE		
19	PRESSURE GAUGE		
20	COMPOUND GAUGE		
21	COUPLING FOR PUMP/MOTOR		
22	BEARING FOR MOTOR		
23	BASKET FOR STRAINER		
24	O RING FOR STRAINER		

Please turn over.

List of Periodic Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
25	SPRAYER	Once every 5 years	
26	IGNITION TRANSFORMER		
27	FLAME DETECTOR RELAY		
28	BALL VALVE FOR OIL SIDE		
29	BALL VALVE FOR STEAM SIDE		
30	SOLENOID VALVE FOR PILOT BURNER		
31	PILOT BURNER		

*Earlier replacement may be needed depending on the operating condition.

*Parts other than those listed above also need to be replaced depending on the condition.

Please contact Japanese trading company to obtain a quotation for spare parts along with this check list.

In case you do not have business with Japanese trading company, please email us to "info-m@volcano.co.jp".

We will send you contact details of the trading company by return.