



MAINTENANCE PARTS LIST FOR VJP BURNER

In order to keep the combustion equipment in the best condition, we recommend the following parts for periodic replacement.

List of Periodic Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
1	F.O. ATOMIZER	Once a Year	
2	CAP NUT		
3	PILOT ATOMIZER		
4	IGNITON ELECTRODE		
5	STABILIZER		
6	SENSOR FOR FLAME EYE (PHOTO CELL)		
7	OIL SEAL FOR PUMP		
8	COUPLING RUBBER		
10	METAL THROAT	Once every 3 years	
11	BEARING FOR MOTOR		
12	COIL FOR MAGNETIC VALVE		
13	COUPLING FOR PUMP / MOTOR		
14	PRESSURE GAUGE		
15	COMPOUND GAUGE		
16	THERMOMETER		
17	OIL STRAINER or STRAINER BASKET		

Please turn over.

List of Periodic Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
18	ATOMIZER BLOCK	Once every 5 years	
19	F.O. PUMP		
20	PILOT BURNER PUMP		
21	RELIEF VALVE		
22	FLAME EYE		
23	FLAME DETECTOR RELAY		
24	MAGNETIC VALVE		
25	DAMPER SOLENOID		
26	IGNITION TRANSFORMER		
27	IGNITION CABLE		
28	CONTROL PANEL TRANSFORMER		
29	SWITCHING POWER SUPPLY		
30	BATTERY FOR PLC		
31	MAGNETIC SWITCH with THERMAL RELAY		
32	AUXILIARY RELAY		
33	HEATER ELEMENT		
34	THERMOSTAT		
35	PRESSURE SWITCH		
36	SEQUENCER (PLC)	Once every 7 ~ 8 years	
37	MOTOR		

*Earlier replacement may be needed depending on the operating condition.

*Parts other than those listed above also need to be replaced depending on the condition.

Please contact Japanese trading company to obtain a quotation for spare parts along with this check list.
In case you do not have business with Japanese trading company, please email us to "info-m@volcano.co.jp".

We will send you contact details of the trading company by return.